

Sets and parts for Sony Venice I

Basic Set for Sony Venice

- Consists of:
- Plate For Sony Venice K2.0017137
 - Bridge Plate Adapter BPA-5 K2.0017138
 - Support Rods 340 mm (13.4 inch), Ø 15 mm K2.66252.0
 - Quick Release Plate, QRP-1 K2.0000399



[KK.0017141](#)

Pro Set for Sony Venice

- Consists of:
- Plate For Sony Venice K2.0017137
 - Bridge Plate Adapter BPA-5 K2.0017138
 - Top Plate For Sony Venice K2.0017024
 - Camera Center Handle CCH-4 K2.0017270
 - Rod mounting bracket RMB-3 K2.0006186
 - Support Rods 340 mm (13.4 inch), Ø 15 mm K2.66252.0
 - Quick Release Plate, QRP-1 K2.0000399
 - Sliding Adapter for CCH-4 K2.0019282



[KK.0017142](#)

EVF bracket Set for Sony DVF-EL200

- Consists of:
- EVF bracket for Sony DVF-EL200 (Venice) K2.021525
 - Mini Viewfinder Bracket MVB-1 K2.006140



[KK.0022326](#)

Venice Extension Unit Set Basic

- Consists of:
- Base Plate for Venice Ext. Unit K2.0024564
 - Top Plate for Venice Ext. Unit K2.0024565
 - Side Bracket Right for Venice Ext. Unit K2.0024566
 - Side Bracket Left for Venice Ext. Unit K2.0024761
 - Cable Clamp for Venice Ext. Unit K2.0024569
 - Back Plate for Venice Ext. Unit K2.0024573
 - Rosette Adapters, RA-6, pair K2.0024574



[KK.0024806](#)

Venice Extension Unit Set Pro

- Consists of:
- Base Plate for Venice Ext. Unit K2.0024564
 - Top Plate for Venice Ext. Unit K2.0024565
 - Side Bracket Right for Venice Ext. Unit K2.0024566
 - Side Bracket Left for Venice Ext. Unit K2.0024761
 - Cable Clamp for Venice Ext. Unit K2.0024569
 - Back Plate for Venice Ext. Unit K2.0024573
 - Rosette Adapters, RA-6, pair K2.0024574
 - Cage Top Handle, CTH-1 K2.66227.0
 - 15mm LWS Rod Console K2.65264.0
 - Rod Mounting Bracket RMB-3 K2.0006186
 - 15mm Reduction Insert K2.66255.0
 - Support Rods 140mm, 5.5in, Ø15mm K2.66254.0
 - Support Rods 240mm/9.4in, Ø15mm K2.66253.0
 - Wooden Handgrip WHG-1 K2.0024965

[KK.0024807](#)



Plate For Sony Venice
[K2.0017137](#)



Top Plate For Sony Venice
[K2.0017024](#)



Base Plate for Venice Ext. Unit,
[K2.0024564](#)



Top Plate for Venice Ext. Unit,
[K2.0024565](#)



Bridge Plate Adapter BPA-5,
[K2.0017138](#)



Camera Center Handle CCH-4,
[K2.0017270](#)



Back Plate for Venice Ext. Unit,
[K2.0024573](#)



Side Bracket Left for Venice Ext. Unit,
[K2.0024761](#)



Sliding Adapter for CCH-4
[K2.0019282](#)



EVF bracket for Sony DVF-EL200 (Venice),
K2.021525



Side Bracket Right for Venice Ext. Unit,
[K2.0024566](#)



Cable Clamp for Venice Ext. Unit,
[K2.0024569](#)

Sets and parts for Sony Venice I/II

Basic Cine Set for Sony Venice 1/2

- Consists of:
- Top Plate for Sony Venice 1/2 K2.0043699
 - Plate for Sony Venice 1/2 K2.0043726
 - Support Rods 340mm/9.4in, Ø15mm K2.66252.0
 - Bridge Plate Adapter BPA-5 K2.0017138
 - Center Camera Handle CCH-4 K2.0017270



[KK.0043758](#)

Pro Cine Set for Sony Venice 1/2

- Consists of:
- Top Plate for Sony Venice 1/2 K2.0043699
 - Plate for Sony Venice 1/2 K2.0043726
 - Support Rods 340mm/9.4in, Ø15mm K2.66252.0
 - Bridge Plate Adapter BPA-5 K2.0017138
 - Side Bracket Right for Sony Venice 1/2 K2.0043731
 - Side Bracket Left for Sony Venice 1/2 K2.0043725
 - Center Camera Handle CCH-4 K2.0017270
 - EVF Bracket for Sony DVF-EL200 (Venice) K2.0021525
 - Mini Viewfinder Bracket MVB-1 K2.0006140



[KK.0043759](#)

Basic Broadcast Set for Sony Venice 1/2

- Consists of:
- Top Plate for Sony Venice 1/2 K2.0043699
 - Plate for Sony Venice 1/2 K2.0043726
 - Support Rods 340mm/9.4in, Ø15mm K2.66252.0
 - Broadcast Shoulder Adapter BSA-1 K2.0043749
 - Center Camera Handle CCH-4 K2.0017270



[KK.0043757](#)

Pro Broadcast Set for Sony Venice 1/2

- Consists of:
- Top Plate for Sony Venice 1/2 K2.0043699
 - Plate for Sony Venice 1/2 K2.0043726
 - Support Rods 340mm/9.4in, Ø15mm K2.66252.0
 - Broadcast Shoulder Adapter BSA-1 K2.0043749
 - Side Bracket Right for Sony Venice 1/2 K2.0043731
 - Side Bracket Left for Sony Venice 1/2 K2.0043725
 - Center Camera Handle CCH-4 K2.0017270
 - EVF Bracket for Sony DVF-EL200 (Venice) K2.0021525
 - Mini Viewfinder Bracket MVB-1 K2.0006140



[KK.0043753](#)



Top Plate for Sony Venice 1/2
[K2.0043699](#)



Plate for Sony Venice 1/2
[K2.0043726](#)



Broadcast Shoulder Adapter BSA-1
[K2.0043749](#)



Side Bracket Right for Sony Venice 1/2
[K2.0043731](#)



Side Bracket Left for Sony Venice 1/2
[K2.0043725](#)